

# Alphabetical Index

Academy of Model Aeronautics .....	5	End Point Adjustments .....	31	Revolution Mixing .....	92
Aileron Differential Adjustment .....	134	End Point Adjustments .....	74	Safety First .....	4
Aileron Set-up, Two Channels ...	28	End Point Adjustments .....	115	Sailplane Receiver Outputs .....	107
Aileron, Rudder Mix .....	131	Exponential .....	46	Sailplane Screens Summary .....	108
Aileron, Rudder Mixers .....	57	Exponential .....	81	Sailplane Switch Defaults .....	107
Aircraft Frequencies .....	5	FAA Guidelines .....	6	Select Sailplane Type .....	109
Airplane Screens Summary .....	23	Fail Safe Function .....	26	Selecting AERO Type .....	24
Airplane Switch defaults .....	22	Fail Safe Function .....	70	Selecting HELI Type .....	68
Alternate Setup Function .....	64	Fail Safe Function .....	111	Servo Centering .....	30
Alternate Setup Function .....	102	Flap, Elevator Mixing .....	39	Servo Centering .....	73
Alternate Setup Function .....	142	Flaps .....	35	Servo Centering .....	114
Auxiliary Channels .....	104	Flight Modes .....	119	Servo Reversing .....	29
Basic Specifications .....	3	Gear or Motor Function .....	117	Servo Reversing .....	72
Battery Fail Safe (Receiver) .....	21	Gyro Sensitivity Selection .....	76	Servo Reversing .....	113
Bi-Directional Mixers .....	55	Heli Screens Summary .....	67	Snap Roll Programs .....	52
Camber .....	128	Heli Switch Defaults .....	66	Spoiler, Elevator Mixing .....	41
Click - Audio Disable .....	16	High Pitch, Low Pitch Trimmers .....	91	Spoilers .....	38
Compensation Mixer .....	93	Hovering Pitch Adjustment .....	86	Spoiron Option .....	27
Compensation Mixers .....	49	Hovering Throttle Adjustment ...	89	Spring Tension, Throttle Ratchet	11
Compensation Mixers .....	144	Initial Screen Display .....	15	Stopwatch, Timer Functions .....	19
Connector Wiring .....	7	Integral Timer .....	20	Stylus Input Keys .....	14
Control Stick Length Adjustment .....	11	Landing Flight Mode .....	126	Switch Alarms .....	71
Cross Trims .....	59	Landing Gear (Retracts) .....	33	Switch Assignments .....	61
Data Copy .....	62	Launch Flight Mode .....	121	Switch Assignments .....	99
Data Copy .....	100	LCD Screen Contrast .....	18	Switch Assignments .....	139
Data Copy .....	140	Mode 1, 2 Conversion - mechanical .....	13	Switched Inverted Set-Up .....	106
Data Reset .....	63	Mode 1, 2 Conversion - software .....	17	Switchless Inverted Set-up .....	105
Data Reset .....	101	Modular Transmitter Battery Pack	8	Throttle Curves .....	87
Data Reset .....	141	Naming Your Airplane .....	25	Throttle Hold .....	90
Differential Adjustment .....	27	Naming Your Helicopter .....	69	Transmitter Antenna .....	9
Direct Servo Controller .....	10	Naming Your Sailplane .....	110	Transmitter Low Voltage Alarm ..	8
Dual Rates .....	43	Offsets (Flight Modes) .....	96	Transmitter RF Meter .....	7
Dual Rates .....	78	PCM Receiver Low Voltage Alarm	7	Transmitter RF Module, Crystals .....	11
Dual Rates .....	135	Pitch Curves .....	84	Trim Memory .....	60
Elevator Mixers .....	132	Primary, Display Power Switches	12	Trim Memory .....	98
Elevator Pre-Sets .....	129	Receiver Outputs, Airplane .....	22	Trim Memory .....	138
Elevator, Camber Mixing .....	133	Receiver Outputs, Heli .....	66	Twin Throttle Option .....	58
Elevator, Flap Mixing .....	41	Reflex Flight Mode .....	124	Unpacking and Charging .....	6
				V-Tail, Mixing Options .....	112